



Where Automation Connects.

## PLX51-DNPS

DNP3 Slave Gateway



September 2, 2025

**RELEASE NOTES**

## Your Feedback Please

We always want you to feel that you made the right decision to use our products. If you have suggestions, comments, compliments or complaints about our products, documentation, or support, please write or call us.

**ProSoft Technology, Inc.**

+1 (661) 716-5100

+1 (661) 716-5101 (Fax)

[www.prosoft-technology.com](http://www.prosoft-technology.com)

[support@prosoft-technology.com](mailto:support@prosoft-technology.com)

PLX51-DNPS Release Notes

For Public Use.

September 2, 2025

ProSoft Technology®, is a registered copyright of ProSoft Technology, Inc. All other brand or product names are or may be trademarks of, and are used to identify products and services of, their respective owners.

## Content Disclaimer

This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither ProSoft Technology nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. Information in this document including illustrations, specifications and dimensions may contain technical inaccuracies or typographical errors. ProSoft Technology makes no warranty or representation as to its accuracy and assumes no liability for and reserves the right to correct such inaccuracies or errors at any time without notice. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by any means, electronic or mechanical, including photocopying, without express written permission of ProSoft Technology. All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components. When devices are used for applications with technical safety requirements, the relevant instructions must be followed. Failure to use ProSoft Technology software or approved software with our hardware products may result in injury, harm, or improper operating results. Failure to observe this information can result in injury or equipment damage.

© 2022 ProSoft Technology. All Rights Reserved.

Printed documentation is available for purchase. Contact ProSoft Technology for pricing and availability.

# Contents

Your Feedback Please .....	2
Content Disclaimer .....	2
<b>1     Start Here</b> .....	<b>4</b>
1.1    About the PLX51-DNPS .....	4
1.2    Release Enhancements .....	5
<b>2     Support, Service &amp; Warranty</b> .....	<b>7</b>
2.1    Contacting Technical Support .....	7
2.2    Warranty Information .....	7

# 1 Start Here

This document highlights the new features, fixes, enhancements and known issues for the PLX51-DNPS Gateway module.

## 1.1 About the PLX51-DNPS

Model	Standards
PLX51-DNPS	UL/cUL; Class1Div2

The PLX51-DNPS gateway provides intelligent routing between DNP3 (Distributed Network Protocol) and either EtherNet/IP™ or Modbus® protocols. The gateways support Ethernet and Serial communications.

PLX51-DNPS gateway is the DNP3 Outstation or Slave.

The PLX51-DNPS allows the user to integrate DNP3 devices over a secure link into a Logix system with minimal effort. No copying or mapping of data in the Logix controller is required as the PLX51-DNPS writes directly into Logix tags.

The PLX51-DNPS allows users to integrate the gateway into a Modbus TCP/IP or serial network. The gateway supports Modbus TCP/IP Client and Server and Modbus RTU protocols.

The PLX51-DNPS module provides DNP3 Secure Authentication 5 which enables the user to connect DNP3 devices to a Logix platform securely. The module also provides a range of diagnostics, statistics and a DNP3 traffic analyzer to assist with fault-finding.

## 1.2 Release Enhancements

Release Version	Release Date	Description
1.003.035	2-Sep-2025	<p><b>New Features:</b></p> <ul style="list-style-type: none"><li>• Added SD card support for Network Parameters storage.</li><li>• Added Dynamic Config Flags to EDS and Input Assembly</li><li>• Added parameter to block DNP3 Event Logging until time is synchronized by a DNP Master.</li><li>• Modbus Auxiliary Writes On-Change-Only option added to Modbus Auxiliary Map.</li></ul> <p><b>Fixes &amp; Changes:</b></p> <ul style="list-style-type: none"><li>• Fixed anomaly where Binary Packed Reads across multiple Unaligned mapped items could result in reading one extra byte in CIP request.</li><li>• Fixed anomalies with SAV5 when authentication challenge is received from the DNP Master.</li><li>• Fixed issue with Modbus comms when Enable Multiple Port Response is enabled and the module uses Modbus RTU232 or RTU485 as a Modbus Master.</li></ul>
1.003.033	8-Sep-2022	<p><b>New Features:</b></p> <ul style="list-style-type: none"><li>• When downloading configuration, allow user to keep or clear current unsolicited messages</li><li>• Support for String Octet DNP object</li><li>• DNP protocol port number is configurable for TCP and UDP</li><li>• Non flag based objects can be event logged</li><li>• Support for time based event logging</li><li>• Support for analog dead bands</li><li>• Support for dual DNP master event unloading (Redundancy)</li><li>• Option to disable event logging when maximum event count is reached</li><li>• Support to inhibit DNP3 communications to master until Modbus communications to end devices are running at startup, after module reset or after power reset</li><li>• Support to inhibit Modbus communications to end devices until DNP3 communications to DNP3 master has been established at startup, after module reset or after power reset</li><li>• Option for DNP3 master to enable unsolicited reporting for each DNP3 object</li></ul>

		<ul style="list-style-type: none"><li>• Option for DNP3 master to configure event class for each DNP3 object</li><li>• IP address check for dual master event unload</li><li>• Support to update module time either using Logix controller or PLX50 configuration utility</li><li>• Option to force DNP3 object online flag if DNP3 object was created without a flag attribute</li><li>• Support for module to reply on the same communications port as the incoming message or to replay on all ports</li><li>• Support for dynamic configuration from DNP3 master. (The PLX51-DNPS will support dynamic configuration command to change the dead band, object class and enable unsolicited message from the DNP3 master and will retain the configuration changes across after the power cycle)</li></ul> <p><b>Fixes &amp; Changes:</b></p> <ul style="list-style-type: none"><li>• Fixed - Issue where events would be read using EtherNet/IP when CIP USB was selected.</li></ul>
1.003.016	30-Aug-2021	<ul style="list-style-type: none"><li>• Minor hardware change</li></ul>
1.003.015	8-Dec-2020	<ul style="list-style-type: none"><li>• Updated EDS file</li><li>• Updated event Logix tag reading to be more efficient</li><li>• Fixed issue where only the first 256 mapped items could use events</li><li>• Fixed issue where a large configuration file being downloaded may cause the flash used to store the configuration file to become corrupt</li></ul>
1.003.012	29-Sep-2020	<ul style="list-style-type: none"><li>• Initial Release</li></ul>

## 2 Support, Service & Warranty

### 2.1 Contacting Technical Support

ProSoft Technology, Inc. is committed to providing the most efficient and effective support possible. Before calling, please gather the following information to assist in expediting this process:

- 1 Product Version Number
- 2 System architecture
- 3 Network details

If the issue is hardware related, we will also need information regarding:

- 1 Module configuration and associated ladder files, if any
- 2 Module operation and any unusual behavior
- 3 Configuration/Debug status information
- 4 LED patterns
- 5 Details about the interfaced serial, Ethernet or Fieldbus devices

**Note:** For technical support calls within the United States, ProSoft Technology's 24/7 after-hours phone support is available for urgent plant-down issues.

North America (Corporate Location)	Europe / Middle East / Africa Regional Office
Phone: +1.661.716.5100 info@prosoft-technology.com Languages spoken: English, Spanish REGIONAL TECH SUPPORT support@prosoft-technology.com	Phone: +33.(0)5.34.36.87.20 france@prosoft-technology.com Languages spoken: French, English REGIONAL TECH SUPPORT support.emea@prosoft-technology.com
Latin America Regional Office	Asia Pacific Regional Office
Phone: +52.222.264.1814 latinam@prosoft-technology.com Languages spoken: Spanish, English REGIONAL TECH SUPPORT support.la@prosoft-technology.com	Phone: +60.3.2247.1898 asiapc@prosoft-technology.com Languages spoken: Bahasa, Chinese, English, Japanese, Korean REGIONAL TECH SUPPORT support.ap@prosoft-technology.com

For additional ProSoft Technology contacts in your area, please visit:  
[www.prosoft-technology.com/About-Us/Contact-Us](http://www.prosoft-technology.com/About-Us/Contact-Us).

### 2.2 Warranty Information

For complete details regarding ProSoft Technology's TERMS & CONDITIONS OF SALE, WARRANTY, SUPPORT, SERVICE AND RETURN MATERIAL AUTHORIZATION INSTRUCTIONS, please see the documents at: [www.prosoft-technology.com/legal](http://www.prosoft-technology.com/legal)